

HEAT BARRIER SYSTEMS, INC.

NEW HOME CONSTRUCTION

House Wrap – Polaralum with White Side Facing Out

General Information:

Type Siding Applications: Hardi Board
Masonite/Vinyl Siding and Aluminum
T-111
T-105
Cedar
Cypress
Or other course products

Suggested Method of Application:

NOTE: Some areas in the country from time to time experience condensation problems due to quick changes in weather conditions.

- 1) Start at bottom of wall. Leave 1" to 1 ½" (inches) above brick ledge or wall base plate open.
- 2) At corners cut Polaralum off 1" (inch) from corners and secure.
- 3) Use staples or plastic cap nails to secure.
- 4) On window and door cut outs, bring Polaralum material to edge of opening, cut off and secure.
- 5) On over lapping, lap down 2" to 3" (inches) then secure with nails or staples and caps.
- 6) On top of wall leave 3" to 4" (inches) open to allow wall to breath.
- 7) Install your desired product over Polaralum.
- 8) Special note: If condensation develops it will dispense itself through evaporation and through top, bottom and side joints which are left open.