



- C) On top of wall leave 3" to 4" (inches) open to allow condensation to dispense itself.**
  - D) Overlap the Polaralum 1" to 2" (inches).**
  - E) Around all openings such as windows, doors, etc, aluminum tape can be used to seal out cold wind and especially heat.**
  - F) Fasten products with plastic caps, staples or plain nails with a head.**
  - G) Suggested nailing pattern required for wall wrap applications, nail on 16" (inch) or 24" (inch) centers.**
- 3) Attach your styro-foam board if necessary for insulation.**
  - 4) Attach your mesh or wire mat, or whatever product you are using to hold the mortar.**
  - 5) Shoot or trowell the mortar, over above item #4.**